

| Part No. | ① Push-In | ② Push-In |
|------------|--------------|--------------|
| 1162-02-02 | 1/8 | 1/8 |
| 1162-25-25 | 5/32 | 5/32 |
| 1162-04-04 | 1/4 | 1/4 |
| 1162-06-04 | 3/8 | 1/4 |
| 1162-06-06 | 3/8 | 3/8 |
| 1162-08-08 | 1/2 | 1/2 |

1162

Push-In Union




Reference
Legris 3106
Parker G2PL

| <i>Nickel Plated</i> | | |
|---------------------------------------|--------------|--------------|
| Part No. | ① Push-In | ② Push-In |
| 1162N-02-02 | 1/8 | 1/8 |
| 1162N-25-25 | 5/32 | 5/32 |
| 1162N-04-04 | 1/4 | 1/4 |
| 1162N-05-05 | 5/16 | 5/16 |
| 1162N-06-06 | 3/8 | 3/8 |
| 1162N-08-08 | 1/2 | 1/2 |
| 1162BHN-04-04 « Bulkhead Union | 1/4 | 1/4 |

1162N

Push-In Union




Reference
Weatherhead 1162

Push-In Fittings

| Part No. | ① Push-In | ② Push-In | ③ Push-In |
|---------------|--------------|--------------|--------------|
| 1164-02-02-02 | 1/8 | 1/8 | 1/8 |
| 1164-25-25-25 | 5/32 | 5/32 | 5/32 |
| 1164-04-04-04 | 1/4 | 1/4 | 1/4 |
| 1164-06-06-06 | 3/8 | 3/8 | 3/8 |
| 1164-08-08-08 | 1/2 | 1/2 | 1/2 |

1164

Union Tee



Reference
Parker 164PL