


Part No.	① Bulkhead Air Brake	② Air Brake
1462BH-04-04	1/4	1/4
1462BH-06-06	3/8	3/8
1462BH-08-08	1/2	1/2
1462BH-10-10	5/8	5/8

1462BH

Bulkhead Union




Reference
Parker 62NBH
Weatherhead 1474

Part No.	① Air Brake	② Air Brake	③ Air Brake
1464-04-04-04	1/4	1/4	1/4
1464-06-06-06	3/8	3/8	3/8
1464-08-08-06	1/2	1/2	3/8
1464-08-08-08	1/2	1/2	1/2
1464-10-10-10	5/8	5/8	5/8

1464

Union Tee




Reference
SAE 100401
Parker 264NTA

Part No.	① Air Brake	② Air Brake
1465-04-04	1/4	1/4
1465-06-06	3/8	3/8
1465-08-08	1/2	1/2
1465-10-10	5/8	5/8

1465

Union Elbow



Reference
SAE 100201
Parker 265NTA

D.O.T.
Air Brake